


Some useful tips for moving around your heat pump remote control



OPERATE / STOP button
Press to start or stop your heat pump

MODE selector button
Select symbol for whether you want heating or cooling

I FEEL COOL DRY HEAT

TEMPERATURE adjustment buttons
Changes how hot or cold you want to be

FAN SPEED setting button
Changes the fan speed

